




---

# Application of Digital Radiography to Weld Inspection for the Space Shuttle External Fuel Tank

**Warren Ussery**  
Lockheed Martin Space Systems Company  
[warren.ussery@maf.nasa.gov](mailto:warren.ussery@maf.nasa.gov)  
504-257-1834




## Background: External Fuel Tank



- **External Fuel Tank Background**


- ET holds cryogenic liquid hydrogen and oxygen fuel for shuttle main engines
- The fuel tanks are 2219 and 2195 Al alloy welded structures
- Material thicknesses range from 0.140" to 1.0"
- Total length of weld undergoing radiography is approx. 3000 feet
- NASA established a goal to replace a significant portion of film with digital radiography



Three ET Domes chosen for digital radiography implementation



## BSX/THZ POD Study



- **Topics**
  - Objectives for film to digital conversion
  - Digital system characteristics
  - POD (Probability of Detection) study
  - Qualification
  - Implementation
  - Lessons Learned




**Film Reader**




**Digital Workstation**



## Objectives for Digital Radiography Conversion




- Eliminate film, chemicals, and associated environmental concerns
- Improve efficiency of radiography process
- Provide enhanced archival capability
- Enhance inspections with digital imaging tools
- Provide electronic distribution of radiography data to multiple NASA sites








# Digital Radiography System Characteristics



- **Two main concerns for digital radiography system:**
  - Sufficient sensitivity to detect small cracks
  - Ability to be integrated into existing External Tank tooling



**Inspection configuration**




**Sun Workstation**



# Digital Radiography System Characteristics




- **Characteristics of the digital x-ray camera**
  - High sensitivity (resolution and contrast)
  - Scintillating fiber faceplate enhances resolution
  - 2K by 2K scientific CCD enhances both resolution and contrast
  - Fiber optic taper transfers the 4" image from the scintillator to the CCD and also protects the CCD by absorbing incident X-rays
  - This design is suitable for low energy inspections (<100 kV)
  - Energies used on ET are in the 40kV to 70kV range







# Digital Radiography System Characteristics




- **Digital x-ray camera technique**
  - Basically the same technique as film for ET welds
  - Yxlon MG165 system
  - Digital technique for 0.320" Al: SFD 40", 70kV, small focal spot, 30 second exposure
  - DR performance is generally improved with lower kV and higher mA than film




→ Figure 2.11. (a) Center-to-center alignment. (b) Offset alignment.



# Digital Radiography System Characteristics





- **Production inspection considerations**
  - Camera is mounted to tooling allowing access to welds
  - Remaining components are cart mounted and mobile
  - Equipment proved to be sufficiently robust for production use
  - Several months of production floor testing combined with system sensitivity resulted in moving forward into next phase of implementation



Frame Weld Inspection


Gore Weld Inspection




Detection of small cracks




# POD Approach



- **Material, weld process, and x-ray detection of weld defects were already well understood**
- **Goal was to ensure that digital x-ray sensitivity was comparable to film**
- **Parallel film and digital inspection of all samples**
- **Defects included the types found in ET welds**
  - Cracks
  - Lack of Fusion
  - Oxide inclusions
  - Heavy Inclusions
  - Porosity with associated cracks
- **90/95 POD for film radiography of cracks in ET welds is 0.28T (28% material thickness)**
- **Success criteria was that digital demonstrate a comparable POD result to film**



Distribution of defects used in POD




Weld repair containing porosity with associated cracks and Lack of Fusion



## POD Approach




- 2219 and 2195 Aluminum alloys included
- POD samples selected by Lockheed Martin and NASA NDE engineers
- Six x-ray interpreters with floor experience performed interpretation
- Worst case weld defects occur in repairs
- Repairs also allow defects to be easily created in a controlled manner
- Typical cracks in ET welds exhibit a 2:1 aspect ratio
- Linear defects (cracks and LF) were selected with a length of  $0.56T$  or smaller







## POD Results




- 255 sample inspections were performed
- Six defects were missed out of the 255 inspections
- Subset of POD samples were dissected to verify flaw sizes
- POD result for digital from binomial analysis was 95/95 for defects 0.28T or smaller
- Comparison of digital and film results on selected POD samples concluded that the images were comparable





DR image (top) and photomicrograph (bottom) of cracks formed at a weld intersection



## Digital Radiography Qualification



- Qualification is performed to demonstrate capability to detect critical defects in production hardware
- Equipment, personnel, tooling, and parts to be inspected resemble production environment as closely as possible
- Tooling designed to position digital radiography system on dome
- Allows adjustment of elevation and angle
- Designed for use on ET T-ring application




Tool and test configuration for qualification testing



# Digital Radiography Qualification




- Two scrap production domes were acquired for the qualification test
- 2219 Al and 2195 Al domes
- Material thicknesses from 0.200" to 1.0" including 0.200" to 0.500" tapered welds
- 63 defects were induced with multiple weld repairs
- Six interpreters with varying experience were selected to read data



Qualification sample consisting of a transverse crack


Qualification Test Article



Distribution of Qualification Defects



## DR Qualification: Blind Results




- Each interpreter given either film or digital data
- DR results: 189 defect shots with 3 missed
- Film results: 189 defect shots with 3 missed
- Neither method had false positives

| Interpreter  | DR Miss  | FR Miss  | DR False Positive | FR False Positive |
|--------------|----------|----------|-------------------|-------------------|
| PO#1         |          | 0        |                   | 0                 |
| PO#2         |          | 3        |                   | 0                 |
| PO#3         |          | 0        |                   | 0                 |
| PA#1         | 1        |          | 0                 |                   |
| PA#2         | 0        |          | 0                 |                   |
| PA#3         | 2        |          | 0                 |                   |
| <b>Total</b> | <b>3</b> | <b>3</b> | <b>0</b>          | <b>0</b>          |

Table 3. Summary of results for the blind comparison.



## DR Qualification: Cumulative Results




- Each interpreter given both film and digital data
- DR results: 378 defect samples with 6 missed
- Film results: 378 defect samples with 6 missed
- DR had 2 false positives, film had none

| Interpreter  | DR Only Miss | FR Only Miss | DR False Positive | FR False Positive |
|--------------|--------------|--------------|-------------------|-------------------|
| PA#1         | 1            | 2            | 0                 | 0                 |
| PO#1         | 0            | 0            | 0                 | 0                 |
| PO#2         | 2            | 3            | 2                 | 0                 |
| PA#2         | 0            | 0            | 0                 | 0                 |
| PA#3         | 2            | 1            | 0                 | 0                 |
| PO#3         | 1            | 0            | 0                 | 0                 |
| <b>Total</b> | <b>6</b>     | <b>6</b>     | <b>2</b>          | <b>0</b>          |

Table 4. Summary of results for the cumulative comparison.



## DR Qualification: Results by Interpreter




- Performance of interpreters appeared to be a function of experience
- PO#2 accounted for two DR and three film misses as well as two DR false positives
  - This interpreter was the least experienced of the six
  - Became a level II just prior to participating in this study

| Interpreter | Method | Dome   | Weld | Position    | Defect Type | Defect Size |
|-------------|--------|--------|------|-------------|-------------|-------------|
| PA#1        |        |        |      |             |             |             |
|             | DR     | ET 105 | HFF3 | 13' 5 1/8"  | CR          | 0.100       |
|             | FR     | ET 65  | HAF1 | 14' 7 3/8"  | CR          | 0.084       |
|             | FR     | ET 65  | HAF2 | 10' 7 1/2"  | CR          | 0.185       |
| PO#2        |        |        |      |             |             |             |
|             | DR     | ET 105 | HFF3 | 13' 5 1/8"  | CR          | 0.100       |
|             | DR     | ET 105 | HFF1 | 20' 5 3/8"  | LF          | 0.210       |
|             | FR     | ET 65  | HAF4 | 16' 8 1/2"  | CR          | 0.133       |
|             | FR     | ET 65  | HAF2 | 16' 10 1/4" | CR          | 0.107       |
|             | FR     | ET 65  | HAG4 | 0' 8 1/4"   | LF          | 0.141       |
| PA#3        |        |        |      |             |             |             |
|             | DR     | ET 65  | HAF2 | 16' 10 1/4" | CR          | 0.107       |
|             | DR     | ET 65  | HAF1 | 4' 6 3/8"   | CR          | 0.123       |
|             | FR     | ET 65  | HAF2 | 10' 7 1/2"  | CR          | 0.185       |
| PO#3        |        |        |      |             |             |             |
|             | DR     | ET 65  | HAF1 | 14' 7 3/8"  | CR          | 0.084       |


Table 5. Details of missed samples.



# Digital Radiography Implementation



5017 T-ring Tooling



5354 Dome Tooling




## Engineering Requirements


---




- **Density: 1000 to 3000 counts in region of interest**
  - Film is logarithmic process versus linear process for digital
  - Digital output is 12 bits so possible values of 0 to 4095
  - 1000 to 3000 range eliminates extremes at either end of range
- **Display system calibration to standard test pattern**
  - NIST traceable light meter
  - Intensity and contrast are measured
- **Secure database and data backup**
- **Cal standards run before and after inspection**
- **Temperature requirement for CCD operation: -12°C max**



# Engineering Requirements




- **Digital radiography calibration block**
  - Vertical and horizontal line pair gauges
  - 1% contrast resolution (97, 98, 99 % of thickness)
  - Inspected before and after each weld






## Lessons Learned



- **Computer literate personnel with film interpretation experience are a plus**
- **Automated tooling speeds acquisition and produces repeatable data**
- **Integration of IQIs into tooling design**
- **Customized interpretation software improves efficiency**
  - All imaging tools available
  - Required tools applied automatically
  - Automatic +15% / -30% penetrameter calculation
  - Playback controls simulate film spool operations




Customized software operates on a series of images



Original software has all tools but only operates on 20 one image at a time



# Conclusion



- **Feasibility Study**
  - HRDR 2K camera was field tested with ET test panels and hardware
  - 2-2T sensitivity, frequently 2-1T sensitivity
  - System proven practical for production inspection
- **POD Study**
  - Limited statistical study conducted on test panels
  - Certified interpreters participated in the study establishing their credentials for future flight hardware inspections
  - Result: 0.28T DR POD comparable to film POD
- **Qualification Study**
  - Flight hardware with worst case defects
  - Certified interpreters
  - Engineering requirements began to be incorporated into inspections
  - Results: DR and film inspections were comparable
- **Implementation**
  - Tooling design and fabrication
  - Finalized engineering requirements
  - Enhanced software

